

## SPRAY NOZZLE COMPONENTS



**MARK 1 ASSEMBLY (NO TIP) SINGLE CLAMP**  
UNI 100 BSOC  
UNI 125 BSOC  
UNI 150 BSOC  
UNI 200 BSOC



**MARK 1 BODY, CAP AND O-RING**  
UNI 100 BCO  
UNI 125 BCO  
UNI 150 BCO  
UNI 200 BCO



**MARK 1 BODY, SINGLE CLAMP AND O-RING**  
UNI 100 BCO  
UNI 125 BCO  
UNI 150 BCO  
UNI 200 BCO



**MARK 1 BODY ONLY**  
UNI 100 B  
UNI 125 B  
UNI 150 B  
UNI 200 B



**MARK 1 CAP**  
UNI RC



**MARK 1 ASSEMBLY (NO TIP) DOUBLE CLAMP**  
UNI 100 BSOC  
UNI 125 BSOC  
UNI 150 BSOC  
UNI 200 BSOC



**MARK 1 OR MARK 2 SINGLE CLAMP**  
UNI 100 SS  
UNI 125 SS  
UNI 150 SS  
UNI 200 SS



**MARK 1 OR MARK 2 DOUBLE CLAMP SET**  
UNI 100 SS *plus* UNI 100 DW  
UNI 125 SS *plus* UNI 125 DW  
UNI 150 SS *plus* UNI 150 DW  
UNI 200 SS *plus* UNI 200 DW



**MARK 1 OR MARK 2 O-RING**  
UNI ODM EPDW  
UNI OVT VITON



**NOZZLE TIP**  
SEE PAGES 11 and 14



**THREADED BALL**  
SEE PAGE 14



**MARK 2 ADAPTER BODY**  
UNI 100 M2 B  
UNI 125 M2 B  
UNI 150 M2 B  
UNI 200 M2 B



**MARK 3 ASSEMBLY BASE**  
SEE PAGES 8 and 9



**QUICK CHANGE TIP**  
SEE PAGES 12 and 13



**QUICK CHANGE BALL**  
SEE PAGES 12 and 13